



BIG DUMP ASSEMBLY GUIDE
MODEL: OPD811
1100 LB ELEC DUMP CART



DETAIL K2 INC.

DK2 POWER USA
4301 S Valley View Blvd STE 10-11
Las Vegas, NV 89103
1-702-331-5353

DETAIL K2, INC.
1080 Clay Avenue Unit 2
Burlington, Ontario, Canada L7L0A1

DK2 USA EAST
6245 Industrial Parkway
Whitehouse, OH 43571

PARTS AND SERVICE 702-331-5353 OR WWW.DK2POWER.COM CONTACT US

1100LB BIG DUMP CART

ELEC DRIVE
HYDRAULIC DUMP
ALL TERRAIN TIRES



OPD811 BIG DUMP ELEC DRIVE HYDRAULIC DUMP Included with Carry-All

STEP 1:

Install both wheels




NOTE: UPON INSPECTION OF PARTS IF YOU FIND ANY DAMAGE OR MISSING PARTS PLEASE CALL DK2 POWER AT **702-331-5353** OR CONTACT US VIA OUR WEBSITE WWW.DK2POWER.COM
WE WILL REPLACE ANY MISSING PARTS TO YOU FREE

PLEASE DO NOT RETURN TO THE STORE

STEP 2:

1. Tip Bucket forward
2. Pin the lift rod

PIN THE LIFT ROD



STEP 3:

1. Assemble axle and nut



STEP 4:


1. Install the right handle assembly with 4 bolts
2. Install the left handle assembly with 4 bolts

4 BOLTS EACH SIDE



STEP 5:

1. TURN ON MACHINE
2. FORWARD AND REVERSE CONTROLS
3. BUCKET LIFT
4. BRAKE



STEP 6:

1. YOUR UNIT IS ALSO SUPPLIED WITH A CARRY ALL
2. TIP WET BUCKET FORWARD AND REMOVE BOLTS
3. SLIDE BUCKET OFF
4. REPLACE WITH CARRY ALL

REMOVE BOLTS





STEP 7:

1. ASSEMBLE THE CARRYALL
2. INSERT DUMP GATE END BETWEEN THE 2 POSTS
3. BOLT THE END POSTS INTO PLACE
4. BOLT THE REAR PANEL INTO PLACE
5. ASSEMBLE SIDES WITH HINGES, FOLD CLOSED AND LATCH
6. USE YOUR CARRYALL TO HAUL BOARDS, FEEDBAGS, CONCRETE BAGS, GRAVEL, DIRT AND MORE.



Ref.No.	Description	Ref.No.2	Description3
1	Bucket	44	M16 lock nut
2	Handle cover	49	Rearaxle mud guard
3	Switch	50	Motor hanger
4	Right handrail	56	16*6.5-8 wheel
5	Brake assemble	57	Rear axle assembly
6	Brake fitting tube	58	Rear axle mud guard
7	Brake fitting flat tube	59	Rear axle controller
8	Electric box	60	Ø19*Ø11*58 spacer
9	Push bar switch	61	Rear axle fitting plate
10	Thermal overload	62	6002 bearing
11	Main switch	63	Right brake fitting
12	Brake handle	64	Brake connect rod
13	Backward switch	65	Left brake fitting
14	Brake cable	66	6204 bearing
15	Left handrail	67	Rear wheels brace
16	Battery	68	95*Ø21*Ø25 spacer
17	Battery box bottem	69	Rear wheel frame
18	Battery box cover plate	70	M16*95 screw
19	Battery cover	71	Rear wheel
20	Charge point	72	Right main frame cover plate
21	Parking cable	73	Left main frame cover plate
22	Bucket fitting plate	74	Electrical box under the baffle
23	Log rod	75	Right brake handle
24	Right short rod	76	Electric push rod switch box
25	23*Ø12*Ø20 Spacer	77	Electric push rod switch box cover
26	Pusher rod	78	Small bucket assembly
27	Left short rod	79	Trailer pin
28	17*Ø11*Ø15 Spacer	80	Small bucket back panel
29	Shocking reduction	81	Switch pin
30	Main frame cover	82	Ø3 The pipe pin
31	Rear wheel frame	83	Ø13*Ø17*53 compression spring
32	Main frame	84	Ø10*Ø27washer
33	Ø4 cotter pin	85	Small bucket front panel
34	Brake cable fitting plate	86	Small bucketfront panel right fixed tube
36	Frone wheel brake rod	87	Small bucketfront panel left fixed tube
37	Ø12*26 pin axle	88	Small bucket left plate
38	Spring	89	Hinge fastener
39	Adjust nut	90	Hinge pin
40	Rearaxle side cover	91	Small bucket right plate
41	Bucket rotate axle	92	Small bottom plate
42	Parking wire fitting plate		





OPERATION – BEFORE USING YOUR DUMP CART

CLEAR AREA OF ALL PEOPLE AND PROPERTY THAT COULD BE DAMAGED. THINK SAFETY. ALLOW STOPPING DISTANTANCE. TAKE CARE ON SLOPES AND HILLS. ONLY ONE OPERATOR SHOULD WORK THIS UNIT. NEVER HAVE ANOTHER PERSON RIDE IN THE BUCKET OR THE CARRYALL. USE THE PARKING BRAKE ON HILLS.

NEVER DRIVE YOUR UNIT WITH THE BUCKET TIPPED FORWARD.

IF YOUR UNIT WILL NOT DRIVE OR DUMP –

1. CHECK THE BATTERY CONNECTIONS.
 2. MAKE SURE YOUR BATTERIES ARE FULLY CHARGED.
 3. TURN THE MASTER SWITCH ON THE PANEL TO ON.
 4. USE THE LEFT HAND CONTROL TO DUMP THE BUCKET
 5. USE THE RIGHT HAND CONTROL TO MOVE FORWARD OR REVERSE
- STAY ALERT OF YOUR SURROUNDING AND PERSONS THAT COULD APEAR IN THE AREA WHILE YOU ARE WORKING.
 - WEAR SAFETY GLASSES, GLOVES AND PROTECTIVE SHOES.

STAY CLEAR OF THE FRAME WHEN BUCKET IS CLOSING.
USE ONLY THE CHARGER PROVIDED TO CHARGE YOUR UNIT.

WEAR PROTECTIVE FOOT WEAR AND TAKE CAUTION WHEN OPERATING ON UNLEVEL OF SLIPPERY GROUND.

NEVER LET CHILDREN OPERATE THIS EQUIPMENT.



PLEASE DO NOT RETURN TO THE STORE

YOU HAVE A 1 YEAR WARRANTY AND DK2 WILL REPLACE A DEFECTIVE PART FOR FREE

CALL US AT 702-331-5353 FOR FAST WARRANTY PARTS AND QUESTIONS

WHAT IS COVERED

DK2 Inc. warrants to the original purchaser of any DK2 product that it will be free and clear of manufacturing defects in workmanship and materials under normal use and service for a period of one (1) year from the date of the original purchase.

If within one (1) year from the original date of purchase this product fails due to defect in material or workmanship. DK2 POWER outdoor power equipment is 1-year parts only warranty no labor.

Upon expiry of one (1) year, Detail K2 will have no further liability related to the product. Detail K2 does not authorize any party, including its authorized distributors or dealers, to offer any other warranty on behalf of Detail K2 Inc.

KOHLER ENGINES – KOHLER CH SERIES ENGINES COMMERCIAL 3 YR PARTS AND LABOR WARRANTY
see your Kohler manual for specific warranty.

DIESEL TRACTORS – Chassis component parts only, no labor, ENGINES – 1 YR KOHLER WARRANTY

DK2 POWER OUTDOOR EQUIPMENT – 1-Year parts only, no labor.

THIS WARRANTY DOES NOT COVER OR APPLY TO:

Damage to the product due to misuse, mishandling and abuse

(b) Improper installation, maintenance and storage

(c) Expendable parts such as nuts and bolts, pins and springs, wiring and switch components, hydraulic hoses and fittings, cutting teeth, cutting chains, cutting blades, throttles, belts and tires.

(d) Normal wear and tear

(e) Consequential damage & incidental damages such as damage to persons or property

(f) Batteries

PROCEDURE FOR OBTAINING AN RETURN AUTHORIZATION

Within the one (1) year warranty period, the purchaser of the product must notify DK2 of the claimed defect and provide proof of original purchase. At this time the validity of the claim will be determined, and if approved replacement parts will be issued.

No returned product will be accepted under warranty unless accompanied by an RGA# issued by Detail K2 Inc.

RESOLUTION FOR A DEFECTIVE PRODUCT

DK2 POWER – Tractors, Chippers, Stump Grinders, Log Splitters, and Outdoor Power Equipment.

Call DK2 at **702-331-5353** in Las Vegas between 8am-4pm M-F Pacific Time.